



MOBILE WORKING TABLE WITH REAR UPSTAND



Length

500, 600, 700, 800, 900, 1000, 1100,
1200, 1300, 1400, 1500, 1600, 1700,
1800, 1900, 2000, 2100, 2200, 2300,
2400, 2500



Width

600, 700, 800

Frame structure in stainless steel AISI 304 fully welded 40x40mm tube, 1.00mm thick, rear legs 80mm advanced, suitable for rounded floor corner. Rear and side welded reinforcement rails. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. With rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. On 2 swivels and 2 braked anti-trace castors, diam. 125mm, and with stainless steel frame.

SKU: N/A



		W		
		600	700	800
	L	Cod.	Cod.	Cod.
	500	T00401001	T00402001	T00403001
	600	T00401002	T00402002	T00403002
	700	T00401003	T00402003	T00403003
	800	T00401004	T00402004	T00403004
	900	T00401005	T00402005	T00403005
	1000	T00401006	T00402006	T00403006
	1100	T00401007	T00402007	T00403007
	1200	T00401008	T00402008	T00403008
	1300	T00401009	T00402009	T00403009
	1400	T00401010	T00402010	T00403010
	1500	T00401011	T00402011	T00403011
	1600	T00401012	T00402012	T00403012
	1700	T00401013	T00402013	T00403013
	1800	T00401014	T00402014	T00403014
	1900	T00401015	T00402015	T00403015
	2000	T00401016	T00402016	T00403016
	2100	T00401017	T00402017	T00403017
	2200	T00401018	T00402018	T00403018
	2300	T00401019	T00402019	T00403019
	2400	T00401020	T00402020	T00403020
	2500	T00401021	T00402021	T00403021

W = Width / Profondità / Breite / Profondeur.
L = Length / Larghezza / Länge / Longueur.