



WORKING TABLE



Length

500, 600, 700, 800, 900, 1000, 1100,
1200, 1300, 1400, 1500, 1600, 1700,
1800, 1900, 2000, 2100, 2200, 2300,
2400, 2500



Width

600, 700, 800

Frame structure in stainless steel AISI 304 fully welded 40x40mm tube, 1.00mm thick, rear legs 80mm advanced, suitable for rounded floor corner. Rear and side welded reinforcement rails. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. On adjustable feet.

SKU: N/A



		W		
		600	700	800
	L	Cod.	Cod.	Cod.
	500	T00101001	T00102001	T00103001
	600	T00101002	T00102002	T00103002
	700	T00101003	T00102003	T00103003
	800	T00101004	T00102004	T00103004
	900	T00101005	T00102005	T00103005
	1000	T00101006	T00102006	T00103006
	1100	T00101007	T00102007	T00103007
	1200	T00101008	T00102008	T00103008
	1300	T00101009	T00102009	T00103009
	1400	T00101010	T00102010	T00103010
	1500	T00101011	T00102011	T00103011
	1600	T00101012	T00102012	T00103012
	1700	T00101013	T00102013	T00103013
	1800	T00101014	T00102014	T00103014
	1900	T00101015	T00102015	T00103015
	2000	T00101016	T00102016	T00103016
	2100	T00101017	T00102017	T00103017
	2200	T00101018	T00102018	T00103018
	2300	T00101019	T00102019	T00103019
	2400	T00101020	T00102020	T00103020
	2500	T00101021	T00102021	T00103021

W = Width / Profondità / Breite / Profondeur.

L = Length / Larghezza / Länge / Longueur.