



## WORKING TABLE WITH REAR UPSTAND



**Length**

500, 600, 700, 800, 900, 1000, 1100,  
1200, 1300, 1400, 1500, 1600, 1700,  
1800, 1900, 2000, 2100, 2200, 2300,  
2400, 2500

**Width**



600, 700, 800

Frame structure in stainless steel AISI 304 fully welded 40x40mm tube, 1.00mm thick, rear legs 80mm advanced, suitable for rounded floor corner. Rear and side welded reinforcement rails. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. With rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. On adjustable feet.

---

**SKU:** N/A



	L	W		
		600	700	800
	Cod.	Cod.	Cod.	
	500	T00201001	T00202001	T00203001
	600	T00201002	T00202002	T00203002
	700	T00201003	T00202003	T00203003
	800	T00201004	T00202004	T00203004
	900	T00201005	T00202005	T00203005
	1000	T00201006	T00202006	T00203006
	1100	T00201007	T00202007	T00203007
	1200	T00201008	T00202008	T00203008
	1300	T00201009	T00202009	T00203009
	1400	T00201010	T00202010	T00203010
	1500	T00201011	T00202011	T00203011
	1600	T00201012	T00202012	T00203012
	1700	T00201013	T00202013	T00203013
	1800	T00201014	T00202014	T00203014
	1900	T00201015	T00202015	T00203015
	2000	T00201016	T00202016	T00203016
	2100	T00201017	T00202017	T00203017
	2200	T00201018	T00202018	T00203018
	2300	T00201019	T00202019	T00203019
	2400	T00201020	T00202020	T00203020
	2500	T00201021	T00202021	T00203021

W = Width / Profondità / Breite / Profondeur.  
L = Length / Larghezza / Länge / Longueur.