



## WORKBENCH WITH 1 DRAWER AND 1 HINGED DOOR AND REAR UPSTAND



<b>Length</b>	540
<b>Width</b>	600, 700, 800
<b>Hinged door opening</b>	left, right

Manufactured in stainless steel AISI 304. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower





cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Optional rear stainless steel upstand H=100mm,

welded and closed on the back, and with R=10mm rounded lower edge. Full extraction drawer mounted on stainless steel rails. Hinged door mounted on removable hinges. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

---

**SKU:** N/A



		W			
		600	700	800	
L	Cod.	Cod.	Cod.	Cod.	
		540	T16001002	T16002002	T16003002
		540	T16101002	T16102002	T16103002

W = Width / Profondità / Breite / Profondeur.  
L = Length / Larghezza / Länge / Longueur.