



WORKBENCH WITH 1 HINGED DOOR





Length	440, 540
Width	600, 700, 800
Hinged door opening	left, right

Manufactured in stainless steel AISI 304. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Optional rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. Hinged door mounted on removable hinges. Internal adjustable shelf. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

SKU: N/A



		W		
		600	700	800
		Cod.	Cod.	Cod.
	L			
	440	T15601001	T15602001	T15603001
	540	T15601002	T15602002	T15603002
	440	T15801001	T15802001	T15803001
	540	T15801002	T15802002	T15803002

W = Width / Profondità / Breite / Profondeur.
L = Length / Larghezza / Länge / Longueur.