



## WORKBENCH WITH 2 HINGED DOORS, CENTRAL DRAWER UNIT AND SLIDING DOORS AND REAR UPSTAND




<b>Length</b>	2460, 2560, 2660, 2760, 2860, 2960, 3060, 3160, 3260, 3360, 3460, 3560
<b>Width</b>	600, 700, 800

Manufactured in stainless steel AISI 304. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Optional rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. Hinged doors mounted on removable hinges, and with internal adjustable shelf. With central 3-drawer unit on stainless steel rails. Sliding doors mounted on hygienic rails, easily removable without mechanical tools, equipped with Internal adjustable shelf. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

---

**SKU:** N/A



		W		
		600	700	800
L		Cod.	Cod.	Cod.
	2460	T21501001	T21502001	T21503001
	2560	T21501002	T21502002	T21503002
	2660	T21501003	T21502003	T21503003
	2760	T21501004	T21502004	T21503004
	2860	T21501005	T21502005	T21503005
	2960	T21501006	T21502006	T21503006
	3060	T21501007	T21502007	T21503007
	3160	T21501008	T21502008	T21503008
	3260	T21501009	T21502009	T21503009
	3360	T21501010	T21502010	T21503010
	3460	T21501011	T21502011	T21503011
	3560	T21501012	T21502012	T21503012

W = Width / Profondità / Breite / Profondeur.  
L = Length / Larghezza / Länge / Longueur.