



WORKBENCH WITH 2 HINGED DOORS, CENTRAL DRAWER UNIT AND SLIDING DOORS



Length

2460, 2560, 2660, 2760, 2860, 2960,
3060, 3160, 3260, 3360, 3460, 3560

Width

600, 700, 800

Manufactured in stainless steel AISI 304. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Optional rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. Hinged doors mounted on removable hinges, and with internal adjustable shelf. With central 3-drawer unit on stainless steel rails. Sliding doors mounted on hygienic rails, easily removable without mechanical tools, equipped with Internal adjustable shelf. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

SKU: N/A



	L	W		
		600	700	800
		Cod.	Cod.	Cod.
2460	T21401001	T21402001	T21403001	
2560	T21401002	T21402002	T21403002	
2660	T21401003	T21402003	T21403003	
2760	T21401004	T21402004	T21403004	
2860	T21401005	T21402005	T21403005	
2960	T21401006	T21402006	T21403006	
3060	T21401007	T21402007	T21403007	
3160	T21401008	T21402008	T21403008	
3260	T21401009	T21402009	T21403009	
3360	T21401010	T21402010	T21403010	
3460	T21401011	T21402011	T21403011	
3560	T21401012	T21402012	T21403012	

W = Width / Profondità / Breite / Profondeur.
L = Length / Larghezza / Länge / Longueur.