



WORKBENCH WITH 2 SLIDING-DOOR UNITS AND REAR UPSTAND


Length	1960, 2160, 2360, 2560, 2760, 2960, 3160, 3360, 3560, 3760
Width	600, 700, 800



Manufactured in stainless steel AISI 304. Working top in AISI 304 sheet, 1.20mm thick, with inner plywood reinforcement and stainless steel lower cover. Rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Optional rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. 2 + 2 sliding doors mounted on hygienic rails, easily removable without mechanical tools. Internal adjustable shelf. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

SKU: N/A



L	W			
	600	700	800	
	Cod.	Cod.	Cod.	
	1960	T20901001	T20902001	T20903001
	2160	T20901002	T20902002	T20903002
	2360	T20901003	T20902003	T20903003
	2560	T20901004	T20902004	T20903004
	2760	T20901005	T20902005	T20903005
	2960	T20901006	T20902006	T20903006
	3160	T20901007	T20902007	T20903007
	3360	T20901008	T20902008	T20903008
	3560	T20901009	T20902009	T20903009
	3760	T20901010	T20902010	T20903010

W = Width / Profondità / Breite / Profondeur.
L = Length / Larghezza / Länge / Longueur.