



SINK ON LEGS WITH 2 STANDARD SINK BOWLS ON THE LEFT



Length	1400, 1500, 1600, 1700, 1800, 1900, 2000
Width	600, 700

Frame structure in stainless steel AISI 304 fully welded 40x40mm tube, 1.00mm thick, with rear legs 80mm advanced, suitable for rounded floor. Rear and side welded reinforcement rails. Top with 2 welded sink bowls, dripping area where indicated, rounded (R=10mm) front upper edge, as well as rounded (R=2mm) side and back edges. Rear stainless steel upstand H=100mm, welded and closed on the back, and with R=10mm rounded lower edge. Front and side upper s.s. cover panels. PVC siphon, drain and stainless steel overflow included. On adjustable feet.

SKU: N/A



	W			S						W			S					
	600									700								
L	Cod.	LxHxP		A	B	C				Cod.	LxHxP		A	B	C			
 	1400	T40101010	400x400x250		500	900	460			T40102010	400x500x250		500	900	460			
	1500	T40101011	400x400x250		500	1000	460			T40102011	400x500x250		500	1000	460			
	1600	T40101012	500x400x250		600	1000	460			T40102012	500x500x300		600	1000	410			
	1700	T40101013	500x400x250		600	1100	460			T40102013	500x500x300		600	1100	410			
	1800	T40101014	500x400x250		600	1200	460			T40102014	600x500x315		700	1100	395			
	1900	T40101015	500x400x250		600	1300	460			T40102015	600x500x315		700	1200	395			
	2000	T40101016	500x400x250		600	1400	460			T40102016	600x500x315		700	1300	395			

S = Sink bowl / Vasche / Becken / Bac.
W = Width / Profondità / Breite / Profondeur.
L = Length / Larghezza / Länge / Longueur.