



CABINET FOR GARMENTS AND SHOES



Length	911, 1123, 1335, 1547, 1795
Number of eyelets	16, 20, 24, 28, 32

Personal locker for shoes storage, manufactured in AISI 304 with scotch brite finish. Each space is equipped with a hinged door mounted on removable hinges, equipped with personal keys. On stainless steel telescopic feet, the rear ones advanced for rounded floor.

SKU: N/A



Technical Data

Code	Overall dimensions mm	Work area dimensions mm	Cleanliness class ISO 14644-1	Air volume (m ³ /h)	Capacity	
	LxPxH	L1xP1xH1			Overall	Shoes
PCZ16	911x595x2600	830x500x1300	ISO4	520	16	16
PCZ20	1123x595x2600	1040x500x1300	ISO4	650	20	20
PCZ24	1335x595x2600	1255x500x1300	ISO4	790	24	24
PCZ28	1547x595x2600	1467x500x1300	ISO4	920	28	28
PCZ32	1795x595x2600	1679x500x1300	ISO4	1050	32	32

Components' description

Main body

made of sturdy painted sheet steel.

Compartment doors

of sliding type gowns, made of painted sheet steel, complete with handles.

Filter Fan Unit

autonomous in the AIR-1-HT series, with a soundproofed anodized aluminium structure with mineral wool panels and radial fan, with backward curved impeller blades, aluminium structure directly connected to the EC electric motor.

Absolute filter

with low pressure drop, H14 class, according to EN1882:2009.

Manometers

differential manometers to control filters clogging.